





# Power Unit 253-42 PARTS LIST



REF. #	PART #	DESCRIPTION	REF. #	PART #	DESCRIPTION
1	876480	Armature	60	696051	Adapter Ring
1A	811350	Baffle	61	696052	Spacer
1B	811292	Armature Fan	70	696038	Spacer
2	877653	Field	100	810882	Strain Reliever
3	869734	Brush	102	861434	Cord Clamp
3B	869691	Brush Holder	103	693104	Screw
3C	811490	Brush Insulator	104	688401	Screw
4	876469	Switch	105	866340	Screw
4A	876392	Handle Plug	106	864137	Screw
5	695854	Cord	108	864136	Brush Holder Screw
11	855284	Bearing	109	694432	Bearing Mount
15	693808	Needle Bearing	110	847564	Snap-ring (Service Only)
15A	693808	Needle Bearing	111	802214	Washer
19	855220	Bearing	112	699085	Self-tapping
35	697673	Idler Assy.	114	852714	Slinger
38	697874	Spindle Assy.	115	848741	Washer
52	876677	Motor Housing, Incl.: Ref. 109, 111, 112, 118	116	697203	Gasket
53	697884	Gear Housing, Incl.: Ref. 15	117	802648	Lock Washer
53A	697684	Intermediate Plate, Incl.: Ref. 15, 15A	118	694015	Self-tapping Screw
57	876612	Handle Assy. Incl.: Ref. 102, 103, 104, 105	122	875861	Belt Clip
			123	876181	Screw
			124	875862	Nut